

ANKER



RAF

Height: 85 cm
 Width: 62 cm
 Depth: 52 cm
 Seat Height: 50 cm
 Seat Width: 48 cm
 Seat Depth: 42 cm
 Arm height: 68 cm

STUDIO



ROXY

Height: 85 cm
 Width: 62 cm
 Depth: 52 cm
 Seat Height: 50 cm
 Seat Width: 48 cm
 Seat Depth: 42 cm

FRAME



1-1-2023

	LEDER <u>D</u>	LEDER <u>R</u>	LEDER <u>S</u>	STOF <u>S1</u>	L60 STOF <u>S2</u>	STOF <u>S3</u>
RAF	439	459	479	389	409	439
ROXY	349	369	389	299	329	349